



95-97 Ranger 12" Sport Trac Adapter Brackets

Kit Contents:

2 Adapter Plates

8 M12x1.75 Bolts

4 Lock nuts

Installation:

1. Remove factory caliper, bracket, and rotor. New rotor can reuse the factory ranger bearings but will require a new seal at a minimum (now would be a great time to replace the bearings as well).



2. Test fit caliper adapter bracket to spindle, the flat plate portion will go towards the rotor. Using an angle grinder, grind the necessary amount of material from the ears of the spindle until you can bolt the new bracket squarely to the spindle.



3. Bolt bracket to spindle. The lock nut should be on the ball joint side and bolt head on rotor side. Tighten to factory caliper bracket specifications.



4. Install 2001-2005 Explorer Sport Trac Rotor onto spindle. If running ABS make sure the new rotor has the abs tone ring on the back.
5. Bolt Caliper to bracket with provided hardware.
6. Enjoy.